# Kershaw



## FC-2013-RW

### Instrumentation LLC

Footage Counter, Model FC - 2013 - RW



#### Overview:

The Model FC- 2013 - RW is an instrument used to measure the length of rolled paper products. It accepts roll widths from 4 - 11 inches, core sizes of  $\frac{1}{2}$  " - 3" and diameters up to 12".

#### Automatic Operation:

The operator places the test roll on the upper spindle, feeds the paper sample around the sensing roller and then positions it either to rewind onto a cardboard core (as shown above) or simply allows the web to flow into a recycle bin. Next the operator presses the start button to begin the test. The instrument automatically displays the speed and footage as the paper is unwound from the supply roll. The test will automatically stop when the roll ends and the total length will remain on the digital display until the next test is started.

#### Specifications:

Motor Speed: Variable from 10 - 200 feet/minute

Size: 2" wide x 20" deep x 25" high

Weight: 60 Pounds Power: 115VAC @ 5A

KERSHAW INSTRUMENTATION LLC

517 Auburn Ave

Swedesboro, NJ 08085 USA

Phone: 856 - 467 - 5482 Fax: 856 - 467 - 2341

www.kershawinst.com